



- Emergency stop strip, mounted on walkway

Maintenance

Manure removing equipment works every day, 7 days a week, 365 days a year.

The Spinder manure removing equipment is maintenance-free and has no grease nipples. The equipment is subject to wear and tear though. Some parts (bearing bushes, corner pulleys, ropes, strips) will need replacing at some point in time.

Sand as cubicle bedding has an abrasive effect; this has a negative influence on the service life of the installation.

Experience has shown that replacement of bearing bushes is sometimes delayed for too long, which may cause unnecessary faults. A service contract may prevent this from happening. Ask your dealer.

Safety

It often happens that manure is pushed below an obstacle. This may increase the risk of jamming. The manure scraper control measures the tractive force; the manure scraper turns off after exceeding the set limit.

It would still be advisable to install safety strips at obstacles. A safety strip turns the manure scraper off at the slightest touch.

Safety strips at wall passages or walkways.

- 61.06.030** Emergency stop strip, 201 - 300 cm wide
- 61.06.031** Emergency stop strip, 301 - 400 cm wide
- 61.06.032** Emergency stop strip, 401 - 500 cm wide
- 61.06.035** Switch box for emergency strip (one for each manure removing system when placing one or more safety strips).